LED Wallsconce



START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-855-855-8926

- Remove the fixture from its original packaging. Next, remove the mounting plate (1c) from within the canopy (2a) by removing the screws (2b). Secure the mounting plate (1c) to the electrical junction box (1a) with screws (1d) provided in the hardware package.
- First remove the outer frame (3c) from the canopy (2a), remove screws (3a) and end piece (3b). Insert the glass shade (2c) into the lamp body aluminum clamp groove. Press the clip (2e) firmly against the glass by means of the nut (2d) rotation, make the clip (2e) open towards the glass. Use the screws (3a) to lock the end piece (3b) onto the glass shade (2c). Then reinstall the outer frame (3c) onto the canopy (2a).
- 3. You are now ready to mount the canopy to the mounting plate. First connect all wires (1b) correctly black to black "L", white to white "N" and the ground wire with provided marrets from the hardware package. Push the canopy (2a) towards the mounting plate (1c) so the holes in the canopy and the mounting plate align. Next, attach the screws (2b) and secure the canopy to the mounting plate.
- **4.** You have now completed the installation of your fixture, enjoy.

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required.



